

D I G I T A L
Alcohol Detector

AlcoHAWK® Slim 2

The AlcoHAWK® Slim 2 offers a sleek and portable design allowing the user to discreetly screen for the presence of alcohol. The innovative folding mouthpiece design with replaceable mouthpiece covers allows for convenient testing of multiple individuals.

Quick Results

Easy to Use

**Folding
Mouthpiece Design**

NEW!

**2 Digit LCD
Display**

Test Counter

NEW!



Q3 Innovations www.q3i.com
2349 Jamestown Avenue, Suite #4, Independence, Iowa 50644
Tel: 319-334-3412 Fax: 319-334-3421 Email: sales@q3i.com

D I G I T A L Alcohol Detector

AlcoHAWK[®] Slim 2

The AlcoHAWK[®] Slim 2 is a breath alcohol screener that quickly screens for the presence of alcohol. The AlcoHAWK[®] Slim 2 is compact, lightweight, and offers an innovative folding mouthpiece design. Simply blow into the unit and within seconds the LCD displays a digital readout. The AlcoHAWK[®] Slim 2 includes Sensor Recognition Technology™ to monitor certain types of abnormal sensor conditions and a test counter to keep track of the number of tests on the unit.

Features

- **Simple and easy to use**
- **Lightweight and compact**
- **Folding mouthpiece design**
- **Three replaceable mouthpiece covers (included)**
- **Two-digit blue back-lit LCD display**
- **Beeps when ready to use**
- **Beeps after breath sample obtained**
- **Semi-conductor oxide sensor**
- **Test counter function**
- **Electronic air flow sensor to improve breath capture quality**

Specifications

Dimensions	4.5 x 1.63 x .75 inches	Digital Display	2 Digits (.00% BAC)
Weight	3.3 oz (94 g) with batteries	Operating Temp	10-40°C (50-104°F)
Housing	Shock Resistant, Molded Plastic	Detection Range	.00% - .40% BAC
Power	2 AA Alkaline Batteries (not included)	Air Sample	5 Seconds
Battery Life	150 Tests ¹	Calibration	Required Periodically ²
Sensor	Sensitive Semi-conductor Sensor	Operation	1 Button
Blowing Time	5 Seconds	Limited Warranty	1 Year
Response Time	5 Seconds ¹	Accuracy	±0.01% at 0.02% BAC ²

¹ Estimates, results may vary.

² Read owner's manual before use to understand proper use, accuracy limitations, and calibration requirements.

³ This device is not to be used to determine if the subject is legal or able to operate any equipment or vehicle

AlcoHAWK[®]

Q3 Innovations

www.q3i.com

2349 Jamestown Avenue, Suite #4, Independence, Iowa 50644

Tel: 319-334-3412 Fax: 319-334-3421 Email: sales@q3i.com